

# INSTRUCTIONS FOR INSTALLING A MINI MAKA VALIDATOR KIT, P/N 1452371, IN A NATIONAL VENDORS® SNACKTRON 1™, SNACKTRON 2™, OR REFRESHTRON 2™ MERCHANDISER

CHECK THE PARTS RECEIVED IN THE KIT WITH THE PARTS LIST IN THESE INSTRUCTIONS. FIGURE 1 SHOWS ALL THE PARTS IN THE KIT. IF ANY PARTS ARE MISSING, CONTACT NATIONAL VENDORS' PARTS DEPARTMENT IMMEDIATELY.

**REFRESHTRON 2 ONLY:** On merchandisers produced prior to serial no. 10329, it wll be necessary to order the latest computer programmed EPROMS. These EPROMS, U2 & U3, are used on the Controller P.C. Board.





VALIDATOR & CONTROLLER ASSY. (1) 1452359



INSERT, UPPER INSTRUCTIONS-VALIDATOR 1452326 (1)



INSERT, LOWER INSTRUCTIONS-VALIDATOR 1452327 (1)



NO-10 EXTERNAL TOOTH LOCKWASHER 2306487 (1)



ANGLE INSERT-VALIDATOR 1452323 (1)



SCREW-#10-32 X .31 THS T/F BLACK 1452312 (2)





CLAMP-.62 4241250 (1)



SCREW-#8-32 X .31 HEX HD T/F BLACK 1451097 (4)



WIRE TIE-SELF CLINCHING (MEDIUM) 2204513 (1)



PCB ASSY. MARS/MAKA INTERFACE 1451336 (1)

### FIGURE 1

## SNACKTRON 1™ and SNACKTRON 2™

1452371 (stacker capacity - 400 bills) contains the following:

Part Number	Description	Quantity
1451097	Screw, #8-32 x .31 Hex Hd. T/F-Black	4
1451316	Door Crossover	1
1451336	PCB AssyMARS/MAKA Interface	1
1452312	Screw, #10-32 x .31 THS T/F Black	2
1452323	Angle Insert, Validator	1
1452326	Insert, Upper Instructions-Validator	1
1452327	Insert, Lower Instructions-Validator	1
1452359	Validator and Controller Assy400	1
1452372	Instructions, Maka Installation	1
2204513	Wire Tie, Self Clinching (Medium)	1
4241250	Clamp, .62	1
5230618	Wire Tie	2
2306487	Lockwasher, No.10 External Tooth	1
	IMPORTANT	.'

This kit can be installed only if merchandiser is equipped with a MARS 5000 or COINTRON 3000 coin changer.

This kit should be installed by qualified technicans using the proper tools for electronic work.

#### KIT INSTALLATION

To install kit, disconnect merchandiser cord from the service outlet, and open cabinet door. Refer to the attached illustrations while performing the following steps.

## 1. REPLACEMENT OF INSTRUCTION INSERTS (UPPER & LOWER)

- A. Remove data access cover (see Figure 2).
- B. Take upper casting off.
- C. Replace upper instruction insert with new insert (P/N 1452326).
- D. Replace upper casting.
- E. Take coin chute assembly off.
- F. Take scavenger assembly off as follows:
  - 1. Remove spring
  - 2. Remove cotter pin
  - 3. Remove scavenger handle
  - 4. Remove 4 screws




FIGURE 2

- H. Take lower casting off.
- I. Replace lower instruction insert with new insert (P/N 1452327).
- J. Replace lower casting.
- K. Replace coin chute assembly and scavenger assembly.

#### 2. INSTALLATION OF MAKA BILL VALIDATOR

- A. Tape angle insert (P/N 1452323) to bill validator (P/N 1452336) (See Figure 2).
- B. Attach validator using four 8-32 x .31 Hex Hd T/F screws.
- C. Tuck validator cable between data access cover and end plate.
- D. Attach validator control box using two 10-32 x .31 THS T/F screws and one No.10 External Tooth Lockwasher.

# 3. MODIFICATION OF CONTROLLER ASSEMBLY

A. Disconnect wire harnesses from controller assembly, (see Figures 3 and 4).

#### NOTE

Access to the main power harness, located at the back of the controller assembly, can be made while removing assembly.

- B. Disconnect coin mechanism interface harness.
- C. Remove controller assembly.
- D. Remove controller assembly cover.
- E. Disconnect coin mechanism interface harnesses from J43, and ribbon wire from J49.
- F. Cut coin mechanism interface harness wire tie and remove from controller assembly.
- G. Remove the MARS 5000 interface PCB.
- H. Attach the MARS/MAKA PCB interface (P/N 1451336).
- I. Attach the door crossover (P/N 1451316) to J71. Reconnect coin mechanism interface harness and ribbon wire to the MARS/MAKA PCB interface.

- J. With wire tie (P/N 5230618), secure the door crossover and the coin mechanism interface harness to the controller assembly.
- K. Replace controller assembly cover.
- L. Replace controller assembly, connecting back power harness and coin mechanism interface harness before installation.
- M. Replace remaining harnesses to controller assembly.
- N. Replace the upper cabinet harness clamp with the new clamp .62 (P/N 4241250) so that both the door crossover and light assembly harness and secured.
- O. Connect door crossover to the validator control box.
- P. Secure door crossover to door by using clamp (P/N 5230618). Attach clamp under top thumb screw on the ribbon clamp, being careful not to pinch display ribbon harness.
- Q. Fasten wire tie (P/N 2204513) around door crossover and light assembly harness, approximately half way between wire clamps.




FIGURE 3




FIGURE 4