

FLEXPAK CHUTE ENHANCEMENT KIT INSTALLATION

M003.1

Order: Chute Enhancement Kit 598,010,000.14

Installation:

1. Remove can/bottle chute from vender.
2. Remove existing liner from can/bottle chute.
3. Install 19½" and 9" kydex dividers on liner as shown.
4. Secure the liner to the can/bottle chute.
5. Install the new can/bottle chute in the vender.
6. Install 8" kydex dividers on liner as shown.

Kit Contents:

1 - 801,809,730.11	Chute Liner
1 - 801,809,750.11	Divider, 19½"
3 - 801,809,760.01	Divider, 9"
2 - 801,809,770.11	Divider, 8"
2 - 901,100,610.11	Pop Rivet, 1/8" Steel

