

## DROP-IN HINGE PIN KITS

M016.0

Order: 491,745,000.04 E-Model Drop-In Hinge Pin Kit  
Includes: 1 - 801,304,930.11 Top Hinge E-Model No Pin  
1 - 900,201,850.31 Carriage Bolt, 5/16-18x1¼  
1 - 800,502,870.21 Bearing Sleeve, 7/16 Brass  
1 - 900,700,080.01 Flat Washer, 14 gauge  
1 - 900,801,020.11 Hex Nut, 5/16-18 Center with Flange

Order: 491,745,100.04 DNCB Model Drop-In Hinge Pin Kit  
Includes: 1 - 801,304,920.11 Top Hinge DNCB Model No Pin  
1 - 900,201,850.31 Carriage Bolt, 5/16-18x1¼  
1 - 800,502,870.21 Bearing Sleeve, 7/16 Brass  
1 - 900,700,080.01 Flat Washer, 14 gauge  
1 - 900,801,020.11 Hex Nut 5/16-18 Center with Flange

### INSTALLATION:

1. Remove existing hinge from main door.
2. Place new top hinge with no pin in position.
3. Install carriage bolt (900,201,850.31).
4. Install bearing sleeve (800,502,870.21) around carriage bolt from bottom side.
5. Install flat washer (900,700,080.01) on carriage bolt from bottom side.
6. Install Hex Nut (900,801,020.11) and secure finger tight.
7. Using a ratchet and ½" socket, tighten to secure.

