

## Technical Bulletin

Bulletin Number: 296

\_ Revision Number: \_

Release Date: August 21, 1985

Revision Date: June 17, 1992

TOMORROW'S MANUFACTURING LEADERSHIP

TODAY

SUBJECT:

Convert the Coke Big Button sequencing columns 1 and

2 to sequence columns 2 and 5.

MODELS AFFECTED:

Pre-Series 90 DNCB 440, 368 and 320 seven (7)

select Coca-Cola venders.

REASON:

To allow one wide and one narrow column to

sequence instead of two wide columns.

SERIAL NUMBER BREAK:

For venders prior to 0001-3162.

**EXCEPTIONS:** 

Venders built on production runs 3164,3166

and 3167 can use the Conversion Kit.

Venders serialized 1954-3161AO to 2003-3161AO and 2656-3161 to 2705-3161AO can

not use the Conversion Kit.

ORDER AS:

B267,014,200.03 - Sequencer Conversion Kit

KIT CONSISTS OF:

2 red and 2 white, 3-way switch Pods with

Jumper Wires installed.

TO INSTALL:

- Unplug vender. 1.
- All work is done in the Sold Out Switch area. 2. Remove Sold Out Switch cover.
- Refer to attached wiring diagram and follow З. these steps:
  - Α. Remove the red and white 3-way terminal pods of the existing harness from the Sold Out Switches on column 1 and column Point the open end of the connectors from column 1 toward the and the open end of column 5 connectors from column 5 toward column 1.
  - Plug the new 3-way terminal pods with в. jumper wires, on column 1 and column 5 Sold Out Switches according to the the diagram on page 2.


Page 1 of 2

- C. Run the jumper wires and push the tabs into the old 3-way terminal pods removed on step 3A as shown on the diagram on page 2.
- 4. Plug in the vender and test for proper operation.
- 5. Coke Big Button should now operate columns 2 and 5. Select button 5 should now operate column 1.

NOTE: If different Select Switch arrangement is desired, for example, Big Button operating column 1 and select switch 5 operating columns 2 and 5. Refer to Service Bulletin 293.

MODELS: PRE-SERIES 90 COCA-COLA
DNCB 440/252-7, 368/216-7 & 320/184-7
NEW TERMINAL PODS WITH JUMPERS

COLUMN 5 COLUMN 1



OLD TERMINAL PODS WITH HARNESS WIRES

SB 296