## Dixie-Na



**Lawrence Street** Ranson, West Virginia 25438 (304) 725-3481 (800) 624-0553

## Service Bulletin

256

Revised: August 22, 1983

DN Dual Adaptables MODELS:

DNCB Dual Adaptables - Not 1 1/4"Deeper

SUBJECT: Replacement Stack - 1 1/4"Deeper

To provide the latest stack as a replacement. REASON:

When a replacement stack assembly is ordered for models listed hereon, a 1 1/4" deeper stack will be furnished.

This stack will be set for 12 oz cans and will contain the following:

1 Rear Spacer - per standard column

1 Rear Spacer - per narrow column

2 Shims - per standard column

1 Shim - left side - per narrow column

1 Oscillator - per standard column 1 vend rotor - per narrow column 1 Sold out bar

1 Cover Vend Motor

## TO INSTALL. DO THIS

- Remove old stack. 1a.
- Remove air deflector from rear wall.
- Remove can/bottle chute.
- Slide new (1 1/4") stack into position push stack all the way to the rear.
- e. Check front stack supports left and right. If they do not support stack completely, "tap" them forward with a hammer.
- Check to see if the bolt holes at rear of stack are aligned with holes in rear wall of cabinet. If not, drill and tap new holes, size 1/4"-20.
- g. Check to see if the bolt holes at top front of stack are aligned with holes in top of cabinet. If not, drill and tap new holes, size 1/4"-20.