

Vend Test Database

Date: 03/03/2004
***Size:** 500 ML
Release Level:

***Model:** 600E SERIES 90
***Type:** PET

ECN #: 001542
Test #: 95-432-18
Country: USA
***Description:** EVIAN ON ICE

Pkg. Dia. (inches): 2.48
Pkg. Dia. (mm): 63

Pkg. Ht. (inches): 8.45
Pkg. Ht. (mm): 214.6

New
 Revised

Instructions:

Wide Column Setup Deep: 2

Qty	Part Number	Description
4	801,812,04x.x1	3/32 flat shim (2 each side next to column wall)
4	801,809,81x.x1	3/32 short flat shim (2 each side)
4	801,810,53x.x1	anti-nosedive shim (2 each side next to bottles)
1	801,809,80x.x1	vending cam, grey
1	801,809,79x.x1	adjustable cam, red

Notes:

Cam set in hole #: 1 **Rear Spacer set in hole #:** 21
Load Package: caps to the back

Narrow Column Setup Deep: 2

Qty	Part Number	Description
1	805,701,14x.x1	can stop shim, right
1	610,071,30x.x3	bottle neck guide assy.
1	801,903,73x.x1	bottle divider assy.
2	800,503,83x.x1	rod & spring assy.
1	801,903,23x.x1	red tube
1	801,903,24x.x1	white tube
1	609,070,63x.x3	filler shim, left (wide part to front of vender)

Notes: Assemble bottle neck guide assy. to rear spacer. Place rod with white tube in hole "C" of rotor. Place rod with red tube in hole "A" of rotor.

Cam set in hole #: 5 **Rear Spacer set in hole #:** 21
Load Package: back bottles first caps to the back, then install bottle divider assy., then front bottles caps to the back.

Discharge Member: large port	Wide Column Capacity: 74
Closure Strip: large port	Narrow Column Capacity: 38
Can Chute Accessories: large port	Total Capacity: 378

