

Vend Test Database

Date: 02/05/2004
 *Size: 12 OZ
 Release 3
 Level:

*Model: 501E SERIES 90
 *Type: NR

ECN #: 001545
 Test #: 99-730-04
 Country: USA
 *Description: ALE 8 ONE

Pkg. Dia. (inches): 2.47
 Pkg. Dia. (mm): 62.74

Pkg. Ht. (inches): 8.04
 Pkg. Ht. (mm): 204.22

New
 Revised

Instructions:

Wide Column Setup Deep: 2

Qty	Part Number	Description
2	609,070,63x.x3	filler shim (1 ea. Side, wide part to front next to column wall)
10	801,812,04x.x1	3/32 flat shim (5 each side)
2	801,809,81x.x1	3/32 short flat shim (1 each side next to bottles)
1	324,010,21x.x3	extension, oscillator paddle w/bottle stop
1	900,302,02x.x1	screw, #8-18x3/4
1	801,809,80x.x1	vending cam, grey
1	801,809,79x.x1	adjustable cam, red



Notes:

Cam set in hole #: 3 Rear Spacer set in hole #: 18
 Load Package:

Narrow Column Setup Deep: 2

Qty	Part Number	Description
1	805,701,14x.x1	can stop shim, right
1	609,011,20x.x3	column wall assy.
1	609,072,80x.x3	rear bottle neck guide assy.
1	609,075,20x.x3	bottle divider assy.
2	800,503,83x.x1	rod & spring assy.
2	801,903,24x.x1	white tube

Notes: Assemble bottle neck guide assy. to rear spacer. Place rod with white tube in hole "A" of rotor. Place rod with white tube in hole "C" of rotor.

Cam set in hole #: 5 Rear Spacer set in hole #: 18
 Load Package: Back bottles first caps to the back then install bottle divider assy., then front bottles caps to the back.

Discharge Member: large port	Wide Column Capacity: 60
Closure Strip: large port	Narrow Column Capacity: 30
Can Chute Accessories: large port	Total Capacity: 300

